

warten Sie, bis das Gerät abgekühlt ist, bevor Sie es reinigen.

24. Das Gerät sollte an einer gut sichtbaren und erreichbaren Steckdose angeschlossen werden.

WARNUNG:

Das Gerät ist nicht mit einer Vorrichtung zur Regelung der Raumtemperatur ausgestattet. Verwenden Sie diesen Heizstrahler nicht in kleinen Räumen, wenn diese von Personen bewohnt werden, die nicht in der Lage sind, den Raum selbständig zu verlassen, es sei denn, dass es eine ständige Aufsicht gewährleistet wird.

Vorbereitung:

1. Vorbereiten Sie einen Kreuzschlitzschraubendreher.
2. Lesen Sie diese Bedienungsanleitung vor der Montage und Verwendung sorgfältig durch. Bewahren Sie diese Anleitung an einem geeigneten und sicheren Ort auf, um sie bei Bedarf wieder verwenden zu können.

Bedienung:

1. Schließen Sie das Gerät an eine Steckdose an. Vergewissern Sie sich, dass die Stromversorgung mit der Nennleistung übereinstimmt. Drücken Sie den Schalter an der Seite der Kontrollbox. Die grüne Kontrollleuchte für "Low" Power blinkt, was bedeutet, dass sich das Gerät im Standby-Modus befindet.
2. Schalten Sie das Gerät entweder mit dem Schalter am Kontrollbox des Heizstrahlers oder mit der Fernbedienung ein.
3. Der Heizstrahler startet auf der niedrigen Stufe, mit jedem Druck auf die ON/POWER-Taste wechselt das Gerät auf die mittlere Stufe, die hohe Stufe und dann wieder auf die niedrige Stufe.
4. Wenn der Heizstrahler nicht mehr benötigt wird, schalten Sie es mit der OFF-Taste am Gerät oder mit der OFF-Taste auf der Fernbedienung aus und ziehen Sie den Netzstecker.

Reinigung:


Trennen Sie das Gerät vor der Reinigung vom Stromnetz. Es sollte mit einem feuchten Tuch abgewischt werden. Verwenden Sie nicht zu viel Wasser.

Entsorgung von Geräten und Batterien



Nach der Umsetzung der europäischen Richtlinie 2002/96/EU in die nationale Rechtsordnung gilt Folgendes:

Elektro- und Elektronikgeräte dürfen nicht über den Hausmüll entsorgt werden. Verbraucherinnen und Verbraucher sind gesetzlich verpflichtet, Elektro- und Elektronikgeräte am Ende ihrer Nutzungsdauer bei den dafür eingerichteten öffentlichen Sammelstellen oder Verkaufsstellen abzugeben. Einzelheiten hierzu werden durch das nationale Recht des jeweiligen Landes festgelegt. Dieses Symbol auf dem Produkt, der Gebrauchsanweisung oder der Verpackung weist darauf hin, dass ein Produkt diesen Vorschriften unterliegt. Durch Recycling, Wiederverwendung der Materialien oder andere Formen der Verwertung von Altgeräten leisten Sie einen wichtigen Beitrag zum Schutz unserer Umwelt.



Instruction Manual

Xavier.WH2000W.S

Cautions:

1. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
CAUTION -- Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
2. The heater must not be located immediately below a socket-outlet.
3. Do not use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
4. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
5. Do not place the unit close to curtain and/or other flammable objects. Otherwise there will be a danger of catching fire.
6. Do not cover the unit with anything during operation or a short time after it's shut down.
7. Do not wrap the power supply cord on the unit.
8. Do not use this unit in place where causticity or volatile air exists, i.e. dust, steam, gas, etc.
9. Do not use this unit as a cloth drier or towel drier.
10. Do not use this unit as a sauna heater.
11. Do not use this unit as a room heater or heat storing.
12. Do not use this unit in place of animal propagating and raising.
13. Do not use this unit in heating system of hot air centre.
14. Do not immerse this unit into water for cleaning.
15. The unit is at high temperature during operation. It keeps hot for a period after shut down. Potential danger would occur when touching it during this period.
16. The unit must be handled with care, and avoid of vibration or hitting.
17. The unit must be securely grounded during operation.
18. When damaged, the unit must be repaired by professional repairing team.
19. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
20. When assembling, keep clear from any board or flammable material.
21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
22. The unit is for household use only. It's not allowed to use in building site, greenhouses, barn or stable where there's flammable dust.
23. The head of the unit is at high temperature during operation. Unplug the unit and wait till it's cool before cleaning.
24. The unit should be plugged in a socket, which is easily visible and reachable.

Part List

No.	Part Name
1	Switch
2	Wall Bracket
3	Tapping Screw
4	Plastic Plug
5	Screw Knob M6*12
6	Remote Control

WARNING:

This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

Preparation:

1. Prepare a cross head screw driver.
2. Read this instruction manual carefully before installation and use. Keep this instruction manual in a proper and safe place for future use in case needed.

Operations:

1. Plug in the unit to a socket. Make sure the power supply is same as rated. Press on the switch on the side of the control box. The green indicator light for "Low" power is flashing, which means it's in standby status.
2. Switch it on by using either the control on the control box of the heater or by using the remote controller.
3. The heater will start on the low setting, each press of the On/Power button will cycle the heater onto the medium setting, high setting and then back to the low setting.
4. When the heater is no longer required, switch off, using the off button on the unit or the off button on the remote controller and unplug the unit.

Disposal of appliances and batteries



After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies:

Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.

Cleaning:

Unplug the unit before cleaning. It should be wiped with wet cloth. Do not use too much water.